


Active 3D Glasses User's Guide



Model: NXG NX-3DG

Active 3D Glasses

Model:NXG NX-3DG

Overview


The wireless NX-3DG active 3D glasses are designed to view 3D content on most 3D projectors with an optional I/R emitter, certain 100Hz or higher CRT monitors, and any Samsung® 3D ready TV with a built in emitter. NXG offers a high quality alternative to higher priced active shutter glasses allowing your family and friends to share and enjoy the full 3D viewing experience

Package Content


Following items are included in the package




- 1, Active 3D Glasses
(contain one piece CR2032 battery)



- 2, Cleaning Cloth




- 3, Storage Pouch




- 4, User's Guide

Product Feature



- 1, Liquid Crystal Lenses
High quality LCD lenses will bring you unbelievable 3D effect
- 2, IR Signal Receiver
- 3, Folding Earpiece
- 4, Power Button
Turn ON: Press the button once;
Turn OFF: Hold the button for about 1.5 seconds.
- 5, LED Indicator
Power ON: LED is on for 1.5 seconds;
Power OFF: LED blinks three times;
Low Battery: LED blinks once every second.



- 6, CR 2032 Battery
- 7, Battery Holder
Note: Remove the insulation tab over the battery holder before using.

Application Guide



or



+



+




Model No.: NX-3DG




System Connection

1 System Connection for 3D TV



2 System Connection for 120 Hz 3D Projector



* Optional items sold separately.

Operation Guide




- 1, Refer to above system connection diagram, set up your system in 3D;
- 2, Press the Power Button to turn on the 3D glasses;
- 3, Verify if the image appears in 3D, if not, please recheck the connection and setting of the whole 3D system;
- 4, Verify if 3D image are eye-strain free,if not,change the 3D sync invert setting;
- 5, Turn off the glasses to save battery if you do not want to use the glasses.

Replacing Battery

When the battery life has less than 2 hours, LED indicator will blink once every second continually, please change the battery. The 3D glasses are powered by one CR2032 lithium/manganese dioxide battery, and the battery is assembled in a drawer-like battery holder.

Step 1

Press the tab of drawer-like battery holder as the arrow mark indicated, and then pulls out the battery holder together with the battery.



Step 2

Replace the old battery, and reassemble a new CR2032 battery in correct polarity.

Step 3

Push the battery holder with the new battery back to its original position.

Specifications

Shutter	Liquid Crystal	
Refresh Rate	120Hz	
Contrast Ratio	1000:1	
Weight(contain battery)	47g	
SYNC Operation	IR	
Transmittance	38+/-2%	
Battery Lifespan (3D Glasses)	70 hours continuously working supported	
Power Supply of 3D Glasses	One CR2032 lithium/manganese dioxide battery (3V, 220mAh)	
Operating Condition	Working Temperature	0°C to 40°C
	Storage Temperature	-10°C to 75°C

Caution

- 1, The 3D glasses only use for 3D content viewing, do not use it as any other general eyewear purpose, such as sunglasses and general eyewear, as such use may result in injury.
- 2, The 3D glasses are powered by CR2032 lithium/manganese dioxide battery, please assembly the battery in correct polarity and do not damage or destroy the battery, or may cause fire or injury.
- 3, Do not place the glasses in a location exposed to direct sunlight, heat, fire or water. This may result in product malfunction or fire.
- 4, Do not let your child to remove the battery of 3D glasses and swallow it,if this happen,consult a doctor immediately.
- 5, Clean the 3D glasses with clean, lint free, dry and soft cloth. Any chemical cleaning agent spray on the 3D glasses may damage the product surface or cause product malfunction.
- 6, Do not apply force to the 3D glasses, dropping or bending may damage the product.
- 7, When watching a 3D video, do not place anything fragile nearby. Involuntary movement or surprised reaction may occur as a result of certain 3D content may result in surrounding objects being broken or hurt yourself.
- 8, Please watch 3D content in a IR signal covered area , and make sure no objection put close to the front of IR emitter.
- 9, 50Hz or 60Hz magnetic fluorescent lamp may cause flicker to your 3D glasses, turn off the lamp if this happens.
- 10, Do not use the 3D glasses if there is any wire exposures or crack to the lens, or may result in a electric shock or injury.

Warning

- 1, Pregnant women, people with heart disease or epilepsy and people who easily nauseous shall not watch 3D content.
- 2, Watching 3D content for a long time may cause headache or eyestrain to you, please stop watching if you have any uncomfortable feeling and take a rest immediately. Please consult a doctor if the feeling do not released.
- 3, Some individuals may experience seizure or other complications when exposed to certain visual images, including flashing lights or patterns that may appear in a video or games. If you or any of your relatives have a history of seizures or epilepsy, consult a doctor before watching.

Active 3D Glasses